

18027 Bishop Avenue  
Carson, CA 90746-4019  
Phone: (800) 374-3872  
Fax: (310) 202-7247  
[www.evroberts.com](http://www.evroberts.com)



## Resin Formulators Technical Data Sheet

### Thawing and Using Pre-mixed & Frozen (PM&F) Cartridges

#### ***General Instructions for Use***

1. Remove cartridge from bag.
2. Place cartridge tip down into water bath at 25 °C (77 °F). Cover to depth of resin but do not allow water into plunger end.

**NOTE: Air thawing is not recommended for cartridges larger than 3cc.**

3. For a 10cc cartridge the thaw time shall be 5-8 min. Do not exceed 10 min.
4. For a 30cc cartridge the thaw time shall be 10-12 min. Extra time may be needed but do not exceed 15 min.
5. Remove cartridge from water bath and wipe off water. NOTE: It is important not to get water into the tip when removing protective cap or replacing the dispensing tip.
6. Remove protective cap and replace with appropriate dispensing tip.

#### **Notice to Buyer: Exclusion of Warranties and Limitation of Liability**

All information supplied by Resin Formulators and E.V. Roberts is considered accurate, but is furnished upon the express condition that the person receiving it shall make their own tests to determine its suitability for their particular purpose. NO WARRANTY IS EXPRESSED OR IMPLIED REGARDING SUCH INFORMATION, THE DATA UPON WHICH THE SAME IS BASED, THE RESULTS TO BE OBTAINED FROM THE USE OF SUCH INFORMATION, OR PRODUCT WILL NOT INFRINGE ANY PATENT. UNDER NO CIRCUMSTANCES SHALL RESIN FORMULATORS OR E.V. ROBERTS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR HANDLING OF ITS PRODUCTS, AND, IN ANY EVENT, LIABILITY FOR BREACH OF ANY WARRANTY OR CONTRACT WITH RESPECT TO SUCH PRODUCTS IS LIMITED TO THE NET SELLING PRICE OF THE PRODUCT, OR THE REPLACEMENT THEREOF, AT THE OPTION OF RESIN FORMULATORS OR E.V. ROBERTS.

**DSoden 10-7-11**