



The Skydrol sample analysis program

How-to guide for your complimentary analysis program

EASTMAN

aviation solutions



Welcome!

We are happy your company has chosen Skydrol™ aviation hydraulic fluids, the most advanced aviation hydraulic fluids supported by recognized experts in phosphate-ester fluid technology.

As a Skydrol customer, you are eligible for our Skydrol sample analysis program at no extra cost. This program provides you with free Skydrol sample kits. Each kit includes:

- A sample bottle (Nalgene, HDPE)
- Sample label
- Plastic bag (polyethylene)
- Box with return shipping address label

To ensure the quality and safety of the program, we have established specific procedures and guidelines that must be followed when using this service. Following these guidelines ensures you get the best results from the program.

Because of safety concerns, the following will not be accepted and will be discarded on arrival:

- Glass bottles
- Bottles that have leaked due to being made of incompatible material or improper lid usage. One-click lids are not suitable.

NOTE: Incorrect sample bottles, incomplete labeling, or insufficient packaging can be a safety hazard.

Our laboratory will reject samples that are not sent in accordance with the following requirements.

In urgent situations, it may be acceptable to use alternative packaging and another sample bottle if a Skydrol sample kit is not immediately available. Make sure the sample bottle material is compatible with Skydrol (HDPE is strongly recommended) and the bottle is clean for safety and quality purposes.

Why is analysis important?

During aircraft operations, hydraulic fluid is subjected to an environment that, in time, alters certain properties of the fluid. No two types of aircraft hydraulic systems operate under the same conditions. Heat, moisture, and overall cleanliness affect the operating life limit of hydraulic fluid. Therefore, the operating life of Skydrol fluids is determined on the basis of both physical and chemical properties rather than by a fixed number of operating hours.

We suggest that you have your hydraulic fluid analyzed periodically to ensure it meets airframe manufacturer in-service limits. Eastman's technical service fluid sampling program offers comprehensive analysis and evaluation of the fluid with recommendations for corrective action when required.

To order Skydrol sample kits, contact your local Eastman customer service representative.

Sampling procedure

The following steps are general guidelines for obtaining a proper sample from your aircraft while ensuring the safety and quality of the results. These guidelines do not supersede the aircraft maintenance manual (AMM) or the airframe manufacturer's recommended sampling procedure.

1. Pressurize and operate the hydraulic system for 10 to 15 minutes. During this time, operate various flight controls to activate valves and thoroughly mix hydraulic fluid.
2. When taking a sample, wear proper personal protective equipment.
3. Wipe off the sampling port with a lint-free cloth. Do not use shop towels or paper products that could produce lint.
4. Allow approximately 250 mL (1 pint) of fluid to drain. This will purge any settled particles from the sampling port.
5. Insert the precleaned sample bottle under the fluid stream and fill, leaving only a small space of air at the top. Withdraw the bottle and cap immediately.
6. Close the drain valve.
7. Fill out the sample label as directed.
8. Service system reservoirs to replace the fluid that was removed.

Labeling samples

Filling out labels completely and correctly is paramount because they are the primary sources for identifying and registering your samples in our system. We encourage you to use the labels received with the sample kit and complete all fields.

Use an ink pen, not a marker or pencil.

All the listed information should be in English. The requirements for the sample label are as follows:

| | |
|---------------------------------------|---|
| Company/airline | Required (e.g., ABC Airlines) |
| Aircraft type | Required (e.g., A320, B737) |
| Aircraft registration number (tail #) | Required (e.g., A-BCDE) |
| City/airport | Required |
| MRO | Optional (if MRO sends sample instead of airline) |
| Hours | Optional (total flight hours of the aircraft) |
| Hydraulic system identification | Required (e.g., 1, center, green) |
| Date of sample | Required |
| Email | Required |
| Remarks | Optional |

Packaging sample bottles

It is imperative that each sample bottle sent to our laboratory for analysis be packed according to the following protocol:

1. Ensure that the bottle lid is tightly sealed.
2. Ensure that each sample bottle is separately labeled and each label is filled out completely.
3. Apply the appropriate GHS label to the bottle. Contact your local sales representative if assistance is needed.
4. Place the sample bottle inside the plastic bag and seal the bag.
5. Put the bagged bottle into the box.
6. Include the completed label in the box—but not inside the plastic bag (in case of accidental leakage, the label will not be destroyed).
7. Ship the sample bottle to the designated laboratory.

NOTE: If your sample is considered hazardous for transport or meets the definition of dangerous goods, do not use the sample packaging provided. Select the appropriate packaging, as it is the shippers responsibility to classify, package, mark, and label hazardous materials for transport pursuant to applicable dangerous goods regulatory requirement (U.S. DOT, ICAO/IATA, IMDG, ADR, etc.).

Shipping

Ship Skydrol aviation hydraulic fluid samples to the appropriate address for your region. If you are unsure which address to use, contact your local sales manager or technical service specialist.

| Americas | Asia Pacific | Europe, Middle East, Africa |
|--|--|---|
| Eastman Chemical Company In-service laboratory 702 Clydesdale Avenue Anniston, Alabama 36201-5390 U.S.A. | SGS-CSTC Standards Technical Services (Shanghai) Co., Ltd. Attn: Chief chemist Building C, No. 399, Shengxia Road, Pudong New District, 201210 Shanghai, China +86-18317189173 | Eastman Chemical Company FAO: Fluids Testing QA Laboratory Corporation Road Newport NP19 4XF U.K. |

Results you can trust

These guidelines have been established to maintain the safety of the sample analysis program, allow us to correctly identify each sample, and provide the highest quality analysis. By following these steps, you help us maintain the high standards that your company expects from Eastman

Aviation Solutions. If you have questions or need more information, contact your local sales manager or technical service specialist. We appreciate your use of Skydrol aviation hydraulic fluid and our complimentary Skydrol sample analysis program.

For more information about the Skydrol sample analysis program, email team.skydrol@eastman.com or visit Eastman.com/Aviation.

EASTMAN
The results of insight™

Eastman Corporate Headquarters
P.O. Box 431
Kingsport, TN 37662-5280 U.S.A.

U.S.A. and Canada, 800-EASTMAN (800-327-8626)
Other locations, +(1) 423-229-2000

www.eastman.com/locations

Although the information and recommendations set forth herein are presented in good faith, Eastman Chemical Company ("Eastman") and its subsidiaries make no representations or warranties as to the completeness or accuracy thereof. You must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. Nothing contained herein is to be construed as a recommendation to use any product, process, equipment, or formulation in conflict with any patent, and we make no representations or warranties, express or implied, that the use thereof will not infringe any patent. NO REPRESENTATIONS OR WARRANTIES, EITHER EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OF ANY OTHER NATURE ARE MADE HEREUNDER WITH RESPECT TO INFORMATION OR THE PRODUCT TO WHICH INFORMATION REFERS AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE.

Safety Data Sheets providing safety precautions that should be observed when handling and storing our products are available online or by request. You should obtain and review available material safety information before handling our products. If any materials mentioned are not our products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

© 2021 Eastman. Eastman brands referenced herein are trademarks of Eastman or one of its subsidiaries or are being used under license. The ® symbol denotes registered trademark status in the U.S.; marks may also be registered internationally. Non-Eastman brands referenced herein are trademarks of their respective owners.